Correction: Remove the last limitation of Section 12.4.4 (Distribution) (The correct limitation is listed at the end of Section 12.4.) – BNF is also modified

Limitations:

- A dist operation shall not be applied to randc variables.
- A dist expression requires that expression contain at least one rand variable.

Updated Constraints BNF – Replace in section 12.4 and Annex A.1.9

```
// from Annex A.1.9
constraint declaration ::=
          [ static ] constraint constraint identifier { { constraint block } }
constraint block ::=
             solve [ priority ] identifier_list before identifier_list ;
            | constraint expression
constraint expression ::=
            expression;
           expression => constraint set
           if ( expression ) constraint_set [ else constraint_set ]
           expression dist { dist list };
           foreach (array_identifier [loop_variables]) constraint_set
constraint set ::=
            constraint expression
          { { constraint_expression } }
dist_list ::= dist_item {, dist_item }
dist item ::=
            value range := expression
          | value_range :/ expression
constraint_prototype ::= [ static ] constraint constraint_identifier
extern constraint declaration ::=
          [ static ] constraint class_identifier :: constraint_identifier { { constraint_block } }
identifier list ::= identifier { , identifier }
loop_variables ::= [ index_indentifier ] { , [ index_indentifier ] }
```

Insert as new 12.10.4 sub-section -- After \$srandom()

12.10.4 \$get_randstate()

The system function \$get_randstate() retrieves the current state of the Random Number Generator (RNG) of an object or process.

The prototype for the \$get randstate() function is:

function string \$get_randstate([class_identifier obj]);

The \$get_randstate() system function returns a copy of the internal state of a RNG. With no arguments, this function returns the state of the RNG associated with the calling process. If the optional object argument is specified, the function returns the state of the RNG associated with the given object.

The RNG state is a string of unspecified length and format.

12.10.5 \$set_randstate()

The system function \$set_randstate() allows setting the current state to of the Random Number Generator (RNG) of an objects or process.

The prototype for the \$set_randstate() function is:

```
function void $set_randstate( string state [, class_identifier obj] );
```

The \$set_randstate() system function copies the given state into the internal state of a RNG. With one argument, this function sets the state of the RNG associated with the calling process. If the optional object argument is specified, the function sets the state of the RNG associated with the given object.

The RNG state is a string of unspecified length and format.

Calling \$set_randstate() with a string value that was not obtained from \$get_randstate() is undefined.

Insert as Section 12.4.10

12.4.10 Functions in Constraints

Some properties are unwieldy or impossible to express in a single expression. For example, the natural way to compute the number of 1's in a packed array uses a loop:

Such a function could be used to constrain other random variables to the number of 1 bits:

```
constraint C1 { length == count ones( v ) };
```

Without the ability to call a function, this constraint requires the loop to be unrolled and expressed as a sum of the individual bits:

Unlike the count_ones function, more complex properties, which require temporary state or unbounded loops, may be impossible to convert into a single expression. The ability to call functions, thus, enhances the expressive power of the constraint language and reduces the likelihood of errors.

To handle these common cases, SystemVerilog allows constraint expressions to include function calls, but it imposes certain semantic restrictions.

- Functions that appear in constraint expressions may not contain output or ref arguments (const ref are allowed). They should be automatic (or preserve no state information) and have no side effects.
- Function that appear in constraints may not modify the constraints, for example, calling rand_mode or constraint_mode methods.
- Functions shall be called before constraints are solved, and their return values shall be treated as state variables.
- Random variables used as function arguments shall establish an implicit variable ordering or priority. Constraints that include only variables with higher priority are solved before other, lower priority, constraints. Random variables solved as part of a higher priority set of constraints become state variables to the remaining set of constraints. For example:

```
class B;
    rand int x, y;
    constraint C { x <= F(y); };
    constraint D { y inside { 2, 4, 8 } };
endclass
```

Forces y to be solved before x. Thus, constraint D is solved separately before constraint C, which uses the values of y and F (y) as a state variables.

— Circular dependencies created by the implicit variable ordering shall result in an error.

 Function calls in active constraints are executed an unspecified number of times (at least once), in an unspecified order.

And change Section 12.4 to:

The declarative nature of constraints imposes the following restrictions on constraint expressions:

- Functions are allowed with certain limitations (see Section 12.4.10).
- Operators with side effects, such as ++ and -- are not allowed.
- randc variables cannot be specified in ordering constraints (see solve...before in Section 12.4.8).
- dist expressions cannot appear in other expressions (unlike inside); they can only be top-level expressions.

Insert as Section 12.4.11

12.4.11 Object handle guards

Constraint expressions may involve multiple objects. Typically, inter-object constraints are written under the assumption that all constrained objects already exist. If, however, some of the objects do not exist, the constraint will fail. Predicate expressions involving object handles can be useful to guard against expressions that should not be evaluated. For example:

```
class SList;
    rand int n;
    rand Slist next;
    constraint sort { n < next.n; }
endclass
```

The sort constraint of the singly-linked list, SList, is intended to assign a random sequence of numbers that is sorted in ascending order. However, the constraint expression will fail on the last element. That condition can be avoided by writing a handle guard using a predicate expression:

```
constraint sort { if( next != null ) n < next.n; }</pre>
```

Predicate expressions involving object handle comparisons prevent the creation of constraints and do not behave as logical relations. Thus, in the sort constraint above, the **if** prevents the creation of a constraint when next == null, which in this case prevents accessing a non-existent object.

Predicate expressions (implication and if...else) involving comparisons between two object handles or an object handle and the constant **null** shall behave as a guard, that is, if the condition expression is false then that constraint expression is disregarded.

Insert as new 12.4.7 section (After if..else constraints)

12.4.7 Iterative Constraints

Iterative constraints allow arrayed variables to be constrained in a parameterized manner using loop variables and indexing expressions.

The syntax to define an iterative constraint is:

The **foreach** construct specifies iteration over the elements of an array. Its argument is an identifier that designates any type of array (fixed-size, dynamic, or associative) followed by a list of loop variables enclosed in square brackets. Each loop variable corresponds to one of the dimensions of the array.

For example:

```
class C;
    rand byte A[] ;
    constraint C1 { foreach ( A [ i ] ) A[i] inside {2,4,8,16}; }
    constraint C2 { foreach ( A [ j ] ) A[j] > 2 * j; }
    endclass
```

C1 constrains each element of the array A to be in the set [2, 4, 8, 16]. C2 constrains each element of the array A to be greater than twice its index.

The number of loop variables must not exceed the number of dimensions of the array variable. The scope of each loop variable is the **foreach** constraint construct, including its constraint_set. The type of each loop variable is implicitly declared to be consistent with the type of array index. An empty loop variable indicates no iteration over that dimension of the array. As with default arguments, a list of commas at the end may be omitted, thus, **foreach**(arr [j]) is a shorthand for **foreach**(arr [j, , , ,]). It shall be an error for any loop variable to have the same identifier as the array.

The mapping of loop variables to array indexes is determined by the dimension cardinality, as described in Section 22.4.

```
// 1 2 3 3 4 1 2 -> Dimension numbers
int A [2][3][4]; bit [3:0][2:1] B [5:1][4];
foreach( A [ i, j, k ] ) ...
foreach( B [ q, r, , s ] ) ...
```

The first **foreach** causes i to iterate from 0 to 1, j from 0 to 2, and k from 0 to 3. The second **foreach** causes q to iterate from 5 to 1, r from 0 to 3, and s from 2 to 1.

Iterative constraints may include predicates. For example:

```
class C;
rand int A[] ;
constraint c1 { arr.size inside {1:10}; }
```

constraint c2 { foreach (A[k]) (k < A.size - 1) => A[k + 1] > A[k]; } endclass

The first constraint, c1, constraints the size of the array A to be between 1 and 10. The second constraint, c2, constraints each array value to be greater than the preceding one, i.e., an array sorted in ascending order.

Predicate expressions within a **foreach** behave as guards against the creation of constraints, and not as logical relations. For example, the implication in constraint c2 above prevents the creation of a constraint when k < A.size() - 1, which in this case prevents an out of bounds access in the constraint.

Index expressions may include loop variables, constants, and state variables. Invalid or out or bound array indexes are not automatically eliminated; users must explicitly exclude these indexes using predicates.

The size method of a dynamic or associative array can be used to constrain the size of the array (see constraint c1 above). If an array is constrained by both size constraints and iterative constraints, the size constraints are solved first, and the iterative constraints next. As a result of this implicit ordering between size constraints and iterative constraints, the size method shall be treated as a state variable within the **foreach** block of the corresponding array. For example, the expression A.size is treated as a random variable in constraint c1, and as a state variable in constraint c2. This implicit ordering can cause the solver to fail in some situations.

Insert as new 12.10 section – Before Section "Random number system functions"

12.10 In-line random variable control

The randomize() method can be used to temporarily control the set of random and state variables within a class instance or object. When the randomize method is called with no arguments, it behaves as described in the previous sections, that is, it assigns new values to all random variables in an object --- those declared as **rand** or **randc** --- such that all of the constraints are satisfied. When randomize is called with arguments, those arguments designate the complete set of random variables within that object; all other variables in the object are considered state variables. For example, consider the following class and calls to randomize:

```
class CA;
    rand byte x, y;
    byte v, w;
    constraint c1 { x < v && y > w );
endclass
CA a = new;
a.randomize();
                         // random variables: x, y
                                                      state variables: v, w
                         // random variables: x
// random variables: v, w
a.randomize( x );
                                                       state variables: y, v, w
                                                      state variables: x, y
a.randomize( v, w );
                         // random variables: w, x state variables: y, v
a.randomize( w, x );
```

This mechanism controls the set of active random variables for the duration of the call to randomize, which is conceptually equivalent to making a set of calls to the rand_mode() method to disable or enable the corresponding random variables. Calling randomize() with arguments allows changing the random mode of any class property, even those not declared as **rand** or **randc**. This mechanism, however, does not affect the cyclical random mode: it cannot change a non-random variable into a cyclical random variable (**randc**), and cannot change a cyclical random variable into a non-cyclical random variables (change from **randc** to **rand**).

The scope of the arguments to the randomize method is the object class. Arguments are limited to the names of properties of the calling object; expressions are not allowed. The random mode of **local** class members can only be changed when the call to randomize has access to those properties, that is, within the scope of the class in which the local members are declared.

12.10.1 In-line constraint checker

Normally, calling the randomize method of a class that has no random variables causes the method to behave as a checker, that is, it assigns no random values, and only returns a status: one if all constraints are satisfied and zero otherwise. The in-line random variable control mechanism can also be used to force the randomize() method to behave as a checker.

The randomize method accepts the special argument **null** to indicate no random variables for the duration of the call, that is, all class members behave as state variables. This causes the randomize method to behave as a checker instead of a generator. A checker evaluates all constraints and simply returns one if all constraints are satisfied, and zero otherwise. For example, if class CA defined above executes the following call:

success = a.randomize(null); // no random variables

Then the solver considers all variables as state variables and only checks whether the constraint is satisfied, namely, that the relation (x < v & & y > w) is true using the current values of x, y, v, and w.

12.11 Randomization of scope variables - ::randomize()

The built-in class randomize method operates exclusively on class member variables. Using classes to model the data to be randomized is a powerful mechanism that enables the creation of generic, reusable objects containing random variables and constraints that can be later extended, inherited, constrained, overridden, enabled, disabled, merged with or separated from other objects. The ease with which classes and their associated random variables and constraints can be manipulated make classes an ideal vehicle for describing and manipulating random data and constraints. However, some less-demanding problems that do not require the full flexibility of classes, can use a simpler mechanism to randomize data that does not belong to a class. The scope randomize method, ::randomize(), enables users to randomize data in the current scope, without the need to define a class or instantiate a class object.

The syntax of the scope randomize method is:

```
scope_randomize ::= // from Annex A.?
[::] randomize ( [ variable_identifier_list ] ) [ with { constraint_block } ]
variable identifier list ::= variable identifier {, variable identifier }
```

The scope randomize method behaves exactly the same as a class randomize method, except that it operates on the variables of the current scope instead of class member variables. Arguments to this method specify the variables that are to be assigned random values. i.e., the random variables.

For example:

```
module stim;
bit[15:0] addr;
bit[31:0] data;
function bit gen_stim();
bit success, rd_wr;
success = ::randomize( addr, data, rd_wr );
return rd_wr ;
endfunction
...
endmodule
```

The function gen_stim calls ::randomize() with three variables as arguments: addr, data, and rd_wr . Thus, ::randomize() assigns new random variables to those variables that are visible in the scope of the gen_stim function. Note that addr and data have module scope, whereas rd_wr has scope local to the function. The above example can also be written using a class:

```
class stimc;
    rand bit[15:0] addr;
    rand bit[31:0] data;
    rand bit rd_wr;
endclass
function bit gen_stim( stimc p );
    bit success;
    success;
    success = p.randomize();
    addr = p.addr;
    data = p.data;
    return p.rd_wr;
endfunction
```

However, for this simple application, the scope randomize method leads to a straightforward implementation.

The scope randomize method returns 1 if it successfully sets all the random variables to valid values, otherwise it returns 0. If the scope randomize method is called with no arguments then it behaves as a checker, and simply returns status.

12.11.1 Adding constraints to scope variables - ::randomize() with

The ::randomize() with form of the scope randomize method allows users to specify random constraints to be applied to the local scope variables. When specifying constraints, the arguments to the scope randomize method become random variables, all other variables are considered state variables.

```
task stimulus( int length );
    int a, b, c, success;
    success = ::randomize( a, b, c ) with { a < b ; a + b < length };
    ...
    success = ::randomize( a, b ) with { b - a > length };
    ...
endfunction
```

The task stimulus above calls ::randomize twice resulting in two sets of random values for its local variables a, b, and c. In the first call variables a and b are constrained such that variable a is less than b, and their sum is less that the task argument length, which is designated as a state variable. In the second call, variables a and b are constrained such that their difference is greater than state variable length.

Insert as section 7.10.1 – In Built-in methods section

7.10.1 Built-in global namespace

SystemVerilog provides a built-in global namespace that contains system types, classes, tasks and functions. The global namespace resides at the top of the hierarchy, like \$root. However, unlike \$root, users cannot insert additional items into the global namespace. The declarations in the global namespace are directly available in any other scope, like system tasks and functions. However, unlike system tasks and functions, the tasks and functions in the global namespace may be redefined by user code in any other scope, but may not be redefined by PLI functions.

The scope resolution operator :: with no identifier on the left can be used to unambiguously access names in the global namespace. For example:

::sys_task(); // unambiguously call the system provided sys_task

Unlike system tasks, functions in the global namespace need not be prefixed with a \$ to avoid collisions with user-defined identifiers. This mechanism allows functional extensions to the language in a backward compatible manner, without the addition of new keywords or polluting local name spaces.

Insert as Section 8.5.3

8.5.3 The foreach loop

The **foreach** construct specifies iteration over the elements of an array. Its argument is an identifier that designates any type of array (fixed-size, dynamic, or associative) followed by a list of loop variables enclosed in square brackets. Each loop variable corresponds to one of the dimensions of the array. The **foreach** construct is similar to a **repeat** loop that uses the array bounds to specify the repeat count instead of an expression.

loop_statement ::=

// from Annex A.6.8

| foreach (array_identifier [loop_variables]) statement

loop_variables ::= [index_indentifier]{ , [index_indentifier] }

Examples:

The number of loop variables must match the number of dimensions of the array variable. Empty loop variable may be used to indicate no iteration over that dimension of the array, and contiguous empty loop variables towards the end may be omitted. Loop variables are automatic, read-only, and their scope is local to the loop. The type of each loop variable is implicitly declared to be consistent with the type of array index. It shall be an error for any loop variable to have the same identifier as the array.

The mapping of loop variables to array indexes is determined by the dimension cardinality, as described in Section 22.4. The **foreach** arranges for higher cardinality indexes to change more rapidly.

// 1 2 3 3 4 1 2 -> Dimension numbers
int A [2][3][4]; bit [3:0][2:1] B [5:1][4];
foreach(A[i,j,k])...
foreach(B[q,r,s])...

The first **foreach** causes i to iterate from 0 to 1, j from 0 to 2, and k from 0 to 3. The second **foreach** causes q to iterate from 5 to 1, r from 0 to 3, and s from 2 to 1 (iteration over the 3^{rd} index is skipped).

When loop variables are used in expressions other than as indexes to the designated array, they are auto-cast into a type consistent with the type of index. For fixed-size and dynamic arrays the auto-cast type is **int**. For associative arrays indexed by a specific index type the auto-cast type is the same as the index type. For associative arrays indexed by a wildcard index (*) the auto-cast type is **unsigned longint**. To use different types, an explicit cast may be used.